

Mounting high and low side tool boxes with A121 and A122 tool box hangers

Mount top end of tool box hanger
to T-slot in gusset as shown

Fasten lower end of
tool box hanger
into end of tool box.

Mount outer edge of tool box
to track using 3 carriage
blots in each T-slot.
Typical spacing is 2 inches
in from each end with 1 bolt
in the center. Score a line
on the bottom of the box
approx. 2 to 2 1/2 inches in
from the edge and drill holes
in box bottom on that line.
Align bolts in track with holes
in box and install box.

